

S213

ВИНТ
Screw

Код / Code	M	Применяемость / Application
S213.16.M8	M8	B213...16 / B219...16
S213.22.M10	M10	B213...22 / B219...22
S213.27.M12	M12	B213...27 / B219...27
S213.32.M16	M16	B213...32 / B219...32
S213.40.M20	M20	B213...40 / B219...40
S213.50.M24	M24	B213...50 / B219...50

